

Quick Start Guide

AngelSense

Keep Your Special Needs Loved One Safe



01

The Kit Content

- 1 AngelSense GPS inside protective sleeve



- 2 Three fasteners to attach the sleeve to garment

- 3 Magnetic key to open the fasteners



- 4 USB magnetic charging cable



WARNING:
CHOKING HAZARD



Small parts not for children under 12 years or any individuals who have a tendency to place inedible objects in their mouths

02

Device Buttons & Light Indicators

GREEN LIGHT

Cellular Reception

Good : 2 blinks

None: 1 blink

RED LIGHT

Charging: Blinks

Fully Charged: Stays On



BLUE LIGHT


GPS Signal

Good: 2 blinks

None: 1 blink

POWER ON

Press top side button for 1 sec until LED lights turn on



RESTART

Press top side & SOS button together until device vibrates. It will then power off and restart.


SOS/CALL

Press to send a call request notification or to call Guardian's phone directly (disable or configure settings in app to prevent accidental requests)

03

Charging

- 1 Charge the device by a window





- 2 Device powers on automatically, red light blinks while charging and remains on when fully charged



See videos in the app

04

Installing The App



Or open www.app.angelsense.com from any browser





Download the **AngelSense Guardian App** that includes a complete user guide and video tutorials. "SIGN IN" with email and password sent by email.

05

Opening Fasteners

- 1 Bring the magnetic key close to the cap and let it snap. Push the key down onto the cap




- 2 Pull the key up to detach the cap from the pin

 See videos in the app


06

Securing Device To Garment

- 1 Insert the device into the pocket




- 2 Put the fastener pin through the material of the garment and the sleeve, and secure using the fastener cap



See videos in the app

07

Wearing Options



There are many creative ways to wear the device




See videos in the app

08


Additional Wearing Options (Sold Separately)




Undershirt



Waterproof Pouch



Armband



Custom Fit Belt

Additional non-removable and sensory friendly wearing accessories can be purchased in the [AngelSense Store](#) in the app

We Are Special Needs Parents Too!

Our Customer Care Team Members are all parents of children with special needs, and we all use AngelSense daily with our own children. We will be happy to share our own experience with you.

Call Us, We Understand!



support@angelsense.com



[1-646-770-2950](tel:1-646-770-2950)



www.angelsense.com/help